## **Gardener 35 planting box**

ID 67447, EAN 8591792674477

## **Assembly instructions**







## Package contents:



Part number / description / number of pieces:

- 1 / Side panel 35 x 15 cm / 12 pieces
- 2 / Side panel 25 x 15 cm / 4 pieces
- 3 / Base bottom 31 x 41 x 7 cm / 3 pieces
- 4 / Bottom insert 26.5 x 36.5 x 3.5 cm / 3 pieces
- 5 / Connecting part 17 x 4 x 4 cm / 24 pieces
- 6 / Connecting part 8 x 4.5 x 3.5 cm / 4 pieces
- 7 / Plug diameter 2 cm / 15 pieces
- 8 / Top cover 3 x 3 x 3 cm / 12 pieces
- 9 / Cover tape 33 cm / 6 pieces
- 10 / Cover tape 23 cm / 6 pieces

## **Assembly instructions**

1. Insert plugs 7 into all circular holes on the sides of the lower part 3.

2. Place the three parts of the base 3 side by side on the ground with the legs down and connect them together by sliding the adjacent part to the side.

3. Connect the two adjacent legs of the inner parts of the base 3 by sliding the connectors 6.

4. Insert the side panels 1 into the holes on the longer sides in the lower parts 3. After inserting, slide them to the side to secure them firmly.

5. Insert the side panels 2 into the holes on the shorter sides in the lower parts 3. After inserting, slide them to the side to secure them firmly.

6. Insert the connecting parts 5 into the holes in the outer corners, the holes of the connectors are facing up. The edges of the side parts of panels 1 and 2 are inserted into the grooves in parts 5.

7. Connect 2 parts of connectors 5 together to create 4 pairs.

8. Insert the formed pairs of connectors 5 between the inner side panels 1, the holes of the connectors are facing up. The edges of the side parts of the panels 1 are inserted into the grooves in the parts 5.

9. Insert additional panels 1 and 2 into the upper holes in side panels 1 and 2 to create the second floor of the box. Once fitted, slide the panels to the side to secure them.

10.Proceed further as in steps 5-7.

11. Insert the upper caps 8 into all the holes in the connecting parts 5.

12. Inside the lower parts of the bottom 3, insert the inserts 4 with the holes facing up.

13. Insert the cover tapes 9 and 10 into the empty grooves on the upper perimeter of the side panels 1 and 2.

14. Insert the cover strips 10 into the empty grooves on the shorter edges of the bottom parts.



**Distributor:** 

RADANSPORT s.r.o. Za Otýlií 10, 370 01 České Budějovice, Česká republika, Czech Republic email: obchod@e-sportshop.cz, tel: +420 387 411 543 www.e-sportshop.cz Country of origin: China

