
NET PLAYZ®

MODEL: NOB365
NAME: 6FT PICKLEBALL TRAINER

ASSEMBLY INSTRUCTIONS

Assembly Video



WE ENCOURAGE OUR CUSTOMERS TO LEAVE REVIEWS OF OUR PRODUCTS ON THE RETAILER'S WEBSITE WHERE THE PRODUCT WAS PURCHASED.

ASSEMBLY TIPS:

1 - Please read the instructions carefully, and follow all assembly, operation and safety instructions properly in order to avoid damage or injury.

2 - Some figures or drawings may not look exactly like your product. Please read and understand the text before beginning each assembly step.

NOTICE!

1 - Check all contents are included before assembly.

2 - Always assemble and disassemble the product under adult supervision.

3 - Check the equipment each time before use.

4 - If any breakage found on the product, please stop assembling or disassembling.

⚠ WARNING: Adult Assembly Required.

⚠ WARNING:

CHOKING HAZARD -- This item contains small parts. Not suitable for children under 3 years.

LIMITED WARRANTY (USA)

TRI-GREAT USA CORP. (the"TGU") assures that the shipped product is free from defects in workmanship and materials when used under normal and proper conditions.

This Limited Warranty covers all defects in materials and workmanship for 90 days from the date of purchase, except for the following situations:

• Damage due to improper usage, negligence, misuse, abuse, transportation, natural disasters, or accidents (including failure to follow the instruction manual).
• Used in commercial applications or rentals.
• Modified or repaired by anyone not authorized by TGU.
• Expendable items such as batteries, light bulbs, fuses, accessories, cosmetic parts, tools and other items that wear out from normal usage.










If you discover a defect after purchasing from a retail store, please return the item with the receipt or purchase invoice to the store where it was bought for further assistance.

Please retain the Instruction Manual. The Model Number is essential if you need to contact us with any questions. Carefully read through the manual to familiarize yourself with all parts and assembly steps. Refer to the Parts List to ensure all parts are included BEFORE beginning assembly.

While we strive to provide the best product, you may still have questions or find that parts are missing.

For assistance, please contact Customer Service at: service@trigreatusa.com

PARTS LIST


1 For FIG.1	2 For FIG.1	3 For FIG.1	4 For FIG.1
 Tube#1 (1pc)	 Tube#2 (1pc)	 Tube#3 (1pc)	 Tube#4 (1pc)
5 For FIG.1	6 For FIG.1	7 For FIG.1	8 For FIG.1
 Tube#5 (1pc)	 Tube#6 (1pc)	 Tube#7 (1pc)	 Tube#8 (1pc)
9 For FIG.2	10 For FIG.2	11 For FIG.3	12 For FIG.3
 Tube#9 (1pc)	 Tube#10 (1pc)	 Tube#11 (2pcs)	 Tube#12 (1pc)
13 For FIG.3	14 For FIG.4	15 For FIG. 8	16 For FIG. 4
 Tube#13 (1pc)	 Tube#14 (w/ clamp) (1pc)	 Ball Bungee Cord (Red) (1pc)	 Tube#16 (1pc)
17 For FIG.5,6	18 For FIG.4	19 For FIG.2	20 For FIG.4
 Ball Bungee Cord (32pcs)	 Screw#1 (3pcs)	 Screw#2 (2pcs)	 Quick Release Pin (1pc)
21 For FIG.6	22 For FIG.6	23 For FIG.6	24 For FIG.7
 Net (1pc)	 Target Webbing (1pc)	 Net Height Webbing (1pc)	 Non-Volley Line (1pc)
25 For FIG.2,4	26 For FIG.4	27 For FIG. 8	
 Allen Wrench (1pc)	 Wrench (1pc)	 Baffle Cloth (1pc)	

ASSEMBLY INSTRUCTIONS

How To Set Up

FIG.1

COMPONENTS	QTY
1	X1
2	X1
3	X1
4	X1
5	X1
6	X1
7	X1
8	X1



Press the button on the tube and insert it into the other tube, aligning the button and hole to connect and lock the tubes.

FIG.2

COMPONENTS	QTY
9	X1
10	X1
19	X2
25	X1




FIG.3

COMPONENTS	QTY
11	X2
12	X1
13	X1

Same process as described in FIG. 1




FIG.4

COMPONENTS	QTY
14	X1
16	X1
18	X3
20	X1
25	X1
26	X1




FIG.4d

Use Allen Wrench and Wrench to lock the U shape frame and tube #14 with Screw#1.




FIG.4c

Connect tubes #14 & #16 using the same method as in FIG. 1.





FIG.4e

Insert the Quick Release Pin to lock the U shape frame and tube #16.






FIG 4b

Loosen the clamp, pull out the upper part of tube #14 and then secure the clamp as picture shows.






FIG.4a

Use Allen Wrench and Wrench to lock the U shape frame and tube with Screw#1.

FIG.5





COMPONENTS	QTY
⑰	X 8
㉑	X 1



Attach the net onto the frame using the Ball Bungee Cords.

TIP:
Start with the corners first.







① USE 2 BALL BUNGEE CORDS TO CONNECT EACH CORNER OF THE NET AND FRAME.

FIG.6


COMPONENTS	QTY
22	X 1
23	X 1
17	X 24




Fasten the Net to the Frame with Ball Bungee Cords.




Position the Target Webbing on the backside of the net and secure the Velcro ends around the tubes.



Position the Net Height Webbing on the backside of the net and secure the Velcro ends around the tubes.






Adjustable Angle: Loosen the clamp, lengthen or shorten the length of the upper tube to adjust the Angle.

FIG.7

COMPONENTS	QTY
24	X 1


Feed the ends of the Non Volley Line under the bottom-side of the tubes and wrap it over the top of the tubes so the Velcro parts are secured.




Standard Pickleball Net Height

FIG.8

COMPONENTS	QTY
27	X1
15	X1



Attach the Baffle Cloth onto the frame and secure the velcro ends around the tubes.




Back


Red



Secure the Baffle Cloth to the cross beam using the red Ball Bungee Cord.




Wider range of hitting target (Beginner)




Narrower range of hitting target (Pro)

YOU ARE NOW READY TO PLAY!

How To Fold Up



Pull out the Quick Release Pin.



Use the Quick Release Pin to lock the supporting tube.

