

NET PLAYZ[®]

MODEL: NOS479
NAME: KICK N' ROLL

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1 - Please read the instructions carefully, and follow all assembly, operation or safety instructions properly in order to avoid damage or injury.
- 2 - Some figures or drawings may not look exactly like your product. Please read and understand the text before beginning each assembly step.

NOTICE!

- 1 - Check all contents are included before assembly.
- 2 - Always assemble and disassemble the product under adult supervision.
- 3 - Check the equipment before each time use it.
- 4 - Any breakage found on the product, please stop assembling or disassembling it.
















WARNING: Adult Assembly Required.



WARNING:







CHOKING HAZARD -- This item contains small parts. Not suitable for children under 3 years.


PARTS LIST

<p>1</p>  <p>Tube (2pcs)</p>	<p>2</p>  <p>Tube (2pcs)</p>	<p>3</p>  <p>Tube (2pcs)</p>
<p>4</p>  <p>Tube (2pcs)</p>	<p>5</p>  <p>Tube (1pc)</p>	<p>6</p>  <p>Tube (2pcs)</p>
<p>7</p>  <p>Fasten hook (2pcs)</p>	<p>8</p>  <p>Ramp (1pc)</p>	<p>9</p>  <p>Screw (16pcs)</p>
<p>10</p>  <p>Screw (6pcs)</p>	<p>11</p>  <p>Screw (4pcs)</p>	<p>12</p>  <p>Wrench (1pc)</p>
<p>13</p>  <p>Allen wrench (1pc)</p>		

ASSEMBLY INSTRUCTIONS

FIG.1


COMPONENTS		QTY
①		X2
②		X2
③		X2
④		X2
⑩		X4
⑬		X1



ASSEMBLY INSTRUCTIONS






FIG.2


COMPONENTS	QTY	COMPONENTS	QTY
⑥	X2	⑧	X1
⑦	X2	⑨	X16
⑫	X1	⑩	X2
⑬	X1		



ASSEMBLY INSTRUCTIONS

FIG.3

COMPONENTS		QTY
5		X1
10		X2
11		X2
12		X1
13		X1



YOU ARE NOW READY TO PLAY!